


# Scanning head - LMK 3010 series

- Incremental, guided linear encoders
- Grating period 1000µm
- Guided scanning head with integrated electronics
- In combination with scale type LMF 3010

**Design 30**  
with scale type LMF 3010



Tolerance principle in accordance with SO8015  
General tolerances in accordance with ISO 2768-fH  
All dimensions in mm

H2 = Reference track marking  
H3 = Direction of scanning head movement for positive counting

## Technical data

- LMK - Scanning head for guided linear encoders
- Grating period 1000µm

Scanning head guided	LMK 3010			
Grating period	1000µm			
Performance	Standard		High Accuracy	
Interface	1Vpp	TTL	1Vpp	TTL
Position error per grating period <sup>1)</sup>	± 2µm		± 0,5µm	
Maximum speed	5m/s limited by the mechanics			
TTL - Interpolation/ 1Vpp signal period				
Signal period <sup>2)</sup> Interpolation	- -	250µm to 1µm 1 to 250	- -	0,5µm or 0,1µm 500 or 2500
Signal period Dividing factor	1000µm or 40µm 1 or 25	- -	20µm 50	- -
Max. output frequency	400KHz	5MHz	400KHz	5MHz
Electrical connection	Cable with M23 coupling 12pin male			
Cable length on the encoder	0,50m - 6,00m			
Power supply	1Vpp: DC 4,0V to 7,0V TTL: DC 5,0V +/- 0,5V			
Power consumption	≤ 1300mW at 5V			
Typ. current consumption	≤ 220mA at 5V (without load)			
Vibration 55 to 2000 Hz	< 200m/s² (EN 60068-2-6)			
Shock 6 ms	< 2000m/s² (EN 60068-2-27)			
Operating temperature	-0°C to 80°C			
Storage temperature	-20°C to 100°C			
Protection	IP67			
Mass	200g			

<sup>1)</sup> The position error per grating period and the accuracy of the grating results together in the encoder specific error; additional deviations caused by mounting and bearing are not considered in this error.

<sup>2)</sup> After 4-edge-evaluation.

# Ordering code

- LMK - Scanning head for guided linear encoders
- Grating period 3000µm

LMK 3010 . . . - 30 - , . . . - . . . - . . .

**Grating period**  
10 = 1000 µm

**Performance**  
S = Standard  
HA = High Accuracy

**Interface**  
07 = TTL  
08 = 1Vpp

**Reference mark**  
RV = Rectangle pulse linked (90° el.) for TTL  
RI = Rectangle pulse linked (360° el.) for 1Vpp

**Functional safety**  
.. = No  
FA = Analog signal (1Vpp) can be used for safety related equipment <sup>1)</sup>

**Incremental signals/Multiplication**

		1Vpp		TTL	
		S	HA	S	HA
01	1-fold	x		x	
05	5-fold			x	
10	10-fold			x	
25	25-fold	x		x	
50	50-fold		x	x	
A3	250-fold			x	
A4	500-fold				x
A9	2500-fold				x

**Pin configuration**  
UJ = 01,02S12,03S12  
J5 = 16S15

**Electrical connection**  
01 = Free cable end  
02S12 = M23-12pin connector male  
03S12 = M23-12pin coupling male  
16S15 = D-SUB-15pin 2-row male

**Cable length**  
0,50 = 0,50 m  
1,00 = 1,00 m  
1,50 = 1,50 m  
2,00 = 2,00 m  
2,50 = 2,50 m  
3,00 = 3,00 m  
4,00 = 4,00 m  
5,00 = 5,00 m  
6,00 = 6,00 m

<sup>1)</sup> Option „FA“ only used for dividing factor „01“.



# Interfaces


## Position values

The EnDat-Interface is a digital, **bi-directional** Interface for measuring systems. With this interface you can read out **position values** and in the measuring system saved informations. This value can also be updated or new values can be saved. Due to the **serial data transfer four signal wires** are enough. The data DATA gets transferred **synchronously** to the form the subsequent electronics given clock frequency CLOCK. The selection from the mode of transmission (position values, parameter, diagnostics,...) is done with mode-commands which are sent from the subsequent electronics to the measuring system.






The clock frequency is variable - depending on the cable length (max. 100m). With propagation electronics, either clock frequencies up to 16MHz are possible or cable length up to 100m. For EnDat encoders the maximum clock frequency is stored in the encoder memory. Propagation-delay compensation is provided for EnDat22.

Transmission frequencies up to 16MHz in combination with large cable length place high technological demands in the cable. Greater cable lengths can be realized with an adapter cable no longer than 6m and an extension cable. As a rule, the entire transmission path must be designed for the respective clock frequency.

Order code	Instruction set	Incremental signals
EnDat2.2	EnDat 2.2	Without



### Pin configuration

<b>Electrical connection:</b> 1SS08 <b>8-pin coupling M12</b> <div></div>								
	Power supply				Absolute position values			
	<b>8</b>	<b>2</b>	<b>5</b>	<b>1</b>	<b>3</b>	<b>4</b>	<b>7</b>	<b>6</b>
	<b>U<sub>P</sub></b>	<b>Sensor U<sub>P</sub></b>	<b>0V</b>	<b>Sensor 0V</b>	<b>DATA+</b>	<b>DATA-</b>	<b>CLOCK+</b>	<b>CLOCK-</b>
	brown/green	blue	white/green	white	grey	pink	violet	yellow

**Cable Shield** is connected with the housing; **U<sub>P</sub>** = Power supply voltage  
**Sensor:** The sensor wire is connected internally with the corresponding power supply.  
Non-used pins or wires must not be assigned!



# Interfaces

SSI +  $\sim 1V_{pp}$






SSI Interface is an unidirectional Interface which can output position values.  
 The Data DATA gets transferred synchronously to the from the subsequent electronic given Clock frequency CLOCK.  
 Additionally three special bits (Error, Warning and Parity) will be transferred

AMO-Encoders with  $\sim 1 V_{pp}$ -Interface are outputting signals which can be highly interpolated.

The sine shaped **incremental signals** A and B are electrically 90° phase shifted and have a signal - B after A - is valid for the in the connection drawing stated movement direction.



## Pin configuration

<b>Electrical connection:</b> 03S17 <b>17-pin coupling M23</b>   												
	Power supply				Increment signals				Absolut position value			
	7	1	10	4	15	16	12	13	14	17	8	9
	U <sub>P</sub>	Sensor U <sub>P</sub>	0 V	Sensor 0 V	A+	A-	B+	B-	DATA+	DATA-	CLOCK+	CLOCK-
	brown/green	blue	white/green	white	brown	green	grey	pink	red	black	violet	yellow

**Cable Shield** is connected with the housing; **U<sub>P</sub>** = Power supply voltage  
**Sensor:** The sensor wire is connected internally with the corresponding power supply.  
 Non-used pins or wires must not be assigned!

# Interfaces

## Pin layouts Fanuc, Mitsubishi BiSS/C<sup>®</sup>

### Fanuc

AMO-Encoders with Fanuc Interface are for connection to a Fanuc-Control.

#### Fanuc Serial Interface - $\alpha$ interface

Order code: Fanuc02  
normal and high speed,  
two-pair transmission.

### BiSS/C

AMO-Encoders with BiSS/C<sup>®</sup> Interface are suitable for the connection with controls, which have the BiSS/C Interface implemented.

#### BiSS/C bidirektionales Protokoll

Order code: BiSS  
The Standard Encoder Profile - 32bit will be used.






### Mitsubishi

AMO-Encoders with Mitsubishi Interface are suitable for connection to a Mitsubishi-Control.

#### Mitsubishi high speed interface

Order code: MitA1-4 (full duplex) -> two pair transmission  
Order code: MitA1-2 (half duplex) -> one pair transmission

### Pin configuration

<div>Electrical connection: 1SS08</div> <div>8-pin coupling M12</div> <div></div>								
	Power supply				Absolute position values			
	8	2	5	1	3	4	7	6
	U <sub>P</sub>	Sensor U <sub>P</sub>	0V	Sensor 0V	DATA+	DATA-	CLOCK+	CLOCK-
	brown/green	blue	white/green	white	grey	pink	violet	yellow

**Cable Shield** is connected with the housing; **U<sub>P</sub>** = Power supply voltage  
**Sensor:** The sensor wire is connected internally with the corresponding power supply.  
Non-used pins or wires must not be assigned!


# Interface

## Incremental signals $\sim 1V_{pp}$













AMO-Encoders with  $\sim 1V_{pp}$ -Interface are outputting signals which can be highly interpolated.

The sine shaped incremental signals A and B are electrically 90° phase shifted and have a signal strenght from 1Vpp. The showed sequence of the outputet signals - B after A - is valid for the in the connection drawing stated movement direction.

The reference mark signal R has a clear as-ignment to the incremental signals.



### Pin configuration

<b>Electrical connection: 16S15</b> <b>15-pin Sub-D-connector</b>													
  													
<b>Electrical connection: 03S12</b> <b>12-pin coupling M23</b>							<b>Electrical connection: 02S12</b> <b>12-pin connector M23</b>						
  							  						
	Power supply				Incremental signals						Other signals		
	4	12	2	10	1	9	3	11	14	7	5/15	8	6
	12	2	10	11	5	6	8	1	3	4	/	7	9
	<b>U<sub>P</sub></b>	<b>Sensor U<sub>P</sub></b>	<b>0V</b>	<b>Sensor 0V</b>	<b>A+</b>	<b>A–</b>	<b>B+</b>	<b>B–</b>	<b>R+</b>	<b>R–</b>	<b>Frei</b>	<b>Diag+</b>	<b>Diag–</b>
	brown/ green	blue	white/ green	white	brown	green	grey	pink	red	black	/	violet	yellow

**Cable Shield** is connected with the housing;  $U_P$  = Power supply voltage

**Sensor:** The sensor wire is connected internally with the corresponding power supply.

Non-used pins or wires must not be assigned!

DIAG-wires must not be assigned.

DIAG-signals are for checking the encoder with AMO-STU-60.




# Interfaces

## Incremental signals □□TTL

AMO-Encoders with □□TTL Interface contain electronic, which form the since-form signals - with or without- Interpolation into digital signals.













The **incremental signals** are outputed as rectangle pulses A+ and B + with 90° el. phase shifting. The **rectandle-mark-signal** is composed from one or more reference impulses R+, which are assigned with the incremental signals. The integrated electro-nic additionally creates the **inverse signals** A-, B- and R- for a safe transmission. The showed sequence of the outputed signals - B after A - is valid for the in the con-nection drawing stated movement direc-tion.

The **measuring step** results throught the distance between two flanks frim the in-cremental signals A+ and B+ throught 1-fold, 2-fold or 4-fold evaluation.



The inverse signals A-, B- und R- are not shown.

### Pin configuration

<b>Electrical connection: 16S15</b> <b>15-pin Sub-D-conector</b> <div></div>													
<b>Electrical connection: 03S12</b> <b>12-pin coupling M23</b> <div></div>					<b>Electrical connection: 02S12</b> <b>12-pin connector M23</b> <div></div>								
	Power supply				Incremental signals						Other signals		
	4	12	2	10	1	9	3	11	14	7	5/15	8	6
	12	2	10	11	5	6	8	1	3	4	/	7	9
	Up	Sensor Up	0V	Sensor 0V	A+	A-	B+	B-	R+	R-	Frei	Diag+	Diag-
	brown/ green	blue	white/ green	white	brown	green	grey	pink	red	black	/	violet	yellow

**Cable Shield** is connected with the housing; **Up** = Power supply voltage

**Sensor:** The sensor wire is connected internally with the corresponding power supply.

Non-used pins or wires must not be assigned!

DIAG-wires must not me assigned!

DIAG-signals are for checking the encoder with AMO-STU-60